



Fig. 1




- 11 Signal light source
- 12 Optical amplifier
- 13 *optical* spectrum analyzer
- 14 Data processing portion
- 15 Displaying portion

Fig. 2.



- S21: Measure input light spectrum $P1(\lambda)$ and output light spectrum $P2(\lambda)$.
- S22: Calculate peak value of input light spectrum $P1(\lambda)$ as an input light level P_{in} , and peak value of output light spectrum $P2(\lambda)$ as an output light level P_{out} . Calculate signal light wavelength λ_s based on $P1(\lambda)$ or $P2(\lambda)$.
- S23: Perform fitting process for portion excluding signal light spectrum in terms of output light spectrum $P2(\lambda)$ data to prepare an ASE spectrum $P3(\lambda)$ to calculate ASE light level $P_{ASE} = P3(\lambda_s)$.
- S24: Calculate gain G and noise figure NF based on P_{in} , P_{out} , and P_{ASE} .

Fig. 3



- S231: Calculate provisional gain GT based on input light level P_{in} and output light level P_{out} .
- S232: Prepare data of light spectrum for assuming ASE $P_{3'}(\lambda) = P_2(\lambda) - GT \times P_1(\lambda)$.
- S233: Perform moving average process for the data of $P_{3'}(\lambda)$.
- S234: Mask data within a wavelength mask range of $\pm \Delta \lambda_{MA}$ of $P_{3'}(\lambda)$ data before and after the signal wavelength λ_s .
- S235: Perform spline interpolation process for the remaining data after masking. Interpolate spectrum within range of $\lambda_s \pm \Delta \lambda_{MA}$. Calculate ASE light spectrum $P_3(\lambda)$.
- S236: Calculate ASE light level $P_{ASE} = P_3(\lambda_s)$.

Fig. 4A




Fig. 4B





Fig. 5



- S51: Measure input light spectrum $P1(\lambda)$ and output light spectrum $P2(\lambda)$ of optical amplifier.
- S52: Recognize peak points in $P1(\lambda)$ or $P2(\lambda)$ as channels, respectively. Determine the number of channels and the wavelengths $\lambda_1, \lambda_2, \dots, \lambda_N$ of respective channels.
- S53: Analyze gains G and noise figure NF by data within the range of $\Delta\lambda_n$ before and after the wavelength λ_n ($n = 1, 2, \dots, N$) of each channel.

10830-079001-1.1.2801

Fig. 6






Fig. 7



- S71: Of the output light spectrum $P2(\lambda)$, mask data within wavelength mask range of $\pm \Delta \lambda_{MA}$ before and after the signal wavelength λ_s .
- S72: Perform curve-fit process for the remaining data after masking. Interpolate a spectrum within the range of $\lambda_s \pm \Delta \lambda_{MA}$. Determine ASE light spectrum $P3(\lambda)$.
- S73: Determine ASE light level $P_{ASE} = P3(\lambda_s)$.

Fig. 8A



Source Spontaneous emission component (SSE light) contained in Signal light

Fig. 8B

